



Repacking the Tank Box Instructions

Step 1.) Starting with the top of the box, tape along the seam, then along the sides. Once finished, turn the box up-side down.



Step 2.) Pack the foot board. Take the foot board's "box" and fold up the center flap.



Position the foot board face down and insert the top part into the slot behind the folded center tab.



Fold sides of the back flap in and fold the folded flap over the footboard. Secure with tape if needed. Once finished, put the packaged footboard into the box face down.



Step 3.) Pack the tank assembly. Secure the recoil belt by looping it around the forward riser bracket.



Secure the handle by looping an elastic band around one side, thread it under the top deck, and back over the other side of the handle.



To prevent remaining water drops from leaking, position a plastic bag between the rubber grommet in the wooden deck and the tank stopper.



Slide the next piece of cardboard over the bottom deck. Flip the tank assembly over and place into the box.



Step 4.) Slide the slotted cardboard insert with a notch cut out over the tank assembly in the box. Make sure the sides are folded up. Place the seat on top of this insert with the wheels up.



Step 5.) Take the next slotted cardboard insert and slide the slots on one side into the slots on the bottom piece of cardboard. Fold the top piece over the seat and do the same to the other side. Press down gently to secure it in place.



Step 6.) Place the siphon pump down the side of the box next to the tank and place the rear spacer, heel rests and bits bag in the cubby holes of the cardboard inserts.



Step 7.) Tape up the bottom of the box as you did in step 1, then flip right side up.

